

KINK BMX

BIKE SIZE CHART

RIDER HEIGHT	BIKE SIZE	TOPTUBE LENGTH
2' 4" - 3' 0" [71 - 91 cm]	12"	12" - 12.5"
2' 8" - 3' 6" [81 - 106 cm]	14"	14" - 14.5"
3' 2" - 4' 0" [96 - 122 cm]	16"	16" - 16.5"
4' 0" - 4' 10" [122 - 147 cm]	18"	18" - 18.5"
4' 10" - 5' 3" [147 - 157 cm]	20"	19.75" - 20.25"
5' 3" - 5' 6" [157 - 168 cm]	20"	20" - 20.5"
5' 6" - 5' 9" [168 - 175 cm]	20"	20.25" - 20.75"
5' 9" - 6' 0" [175 - 183 cm]	20"	20.5" - 21"
6' 0" - 6' 3" + [183 - 190 cm +]	20"	20.75" - 21.5"
5' 4" - 6' 2" + [162 - 188 cm +]	26"	22" - 22.5"

Notes

1. If the rider is still growing you may want to buy a slightly bigger size.
2. This is only a general guide, fine tuning comes from experience, riding style and preference.
3. For safe and comfortable riding, there should be a clearance of at least 1" to 2" between the riders crotch and top tube of the bike.